



Instructions for Applying COTE-L's CEASEFIRE™ Two-Part Epoxy

Notes:

- A. Be aware that the correct mix ratio for both is 100 parts of A to 24-27 parts of B by weight.
- B. Also be aware that once parts A and B are mixed, the work life of the mixed system is approximately 2-1/2 hours at room temperature.

Instructions:

1. Mix full container of part A first thoroughly to compensate for any settling.
NOTE: DO NOT ADD PART B UNTIL PART A IS THOROUGHLY MIXED.
2. Add the correct amount (based on weight) of Part B to Part A.
3. Mix thoroughly until uniform.
4. Apply with brush, roller, or trowel to desired thickness. A minimum thickness of 5mil (0.005") is recommended. Thicker coatings will enhance the fire protective characteristics of these coatings.
5. To reduce viscosity you may use up to 10% by weight of paint thinner. (lacquer thinners are recommended)
6. Material should be tack free in approximately 10 hours at room temperature.
7. Full cure is achieved in 2 days at room temperature.
8. Mild heat may be applied to speed up cure. Please consult manufacturer for instructions.
9. Painting over these coatings will reduce their effectiveness.